



## SU-16A RIFLE PARTS LIST

Part # 202 Exchange Only

100-BARREL  
102-BARREL NUT  
104-BARREL EXTENSION  
108-BARREL RETAINER  
110-BOLT  
112-EXTRACTOR  
114-EXTRACTOR AXIS  
116-EJECTOR  
118-FIRING PIN  
120-BOLT CARRIER  
122-OPERATING HANDLE  
124-PISTON ROD  
126-CAM PIN  
128-RECOIL SPRING CATCH  
130-PISTON HEAD  
132-RECOIL SPRING TUBE  
134-FIRING PIN PIN  
136-GAS BLOCK  
138-GAS HEAD  
140-TRIGGER BLOCK  
142-HAMMER  
144-SEAR  
145-SEAR SPRING PIN  
146-SAFETY  
148-FOREND AXIS  
150-STOCK SPACER-16  
152-MAG SNAP PIN-SHORT  
154-SPACER-29  
158-ASSEMBLY PIN  
159-MAG SNAP PIN-LONG  
172-FOREND LOCK SPRING  
174-RECOIL SPRING  
176-MAGAZINE CATCH SPRING  
178-HAMMER SPRING  
180-SEAR SPRING  
182-TRIGGER SPRING  
186-STOCK PIN SPRING  
188-MAGAZINE SNAP SPRING  
190-BOLT STOP SPRING  
192-FOREND SPREADER SPRING  
194-EXTRACTOR SPRING  
196-EJECTOR SPRING  
198-MAGAZINE SPRING  
202-RECEIVER  
203-DRIVER HOUSING  
204-MAG WELL  
205-PHILLIPS DRIVER  
206-FRONT SIGHT  
207-RED O'RING  
208-TRIGGER  
210-EXTRACTOR SPRING BUFFER  
212-STOCK-RIGHT  
214-STOCK-LEFT  
216-RECEIVER SPREADER  
218-FOREND-RIGHT  
220-FOREND-LEFT  
226-FOREND LOCK  
228-BOLT STOP  
230-REAR SIGHT-PEEP  
232-REAR SIGHT LOCK  
234-MAG CATCH  
236-FRONT SIGHT SCREW  
240-FRONT SIGHT POST  
244-RECOIL PAD  
252-MAGAZINE HOUSING  
254-MAGAZINE FOLLOWER  
256-MAGAZINE PLATE  
258-MAGAZINE BOTTOM  
268-SAFETY/OPERATION MANUAL  
274-EJECTOR PIN  
276-RECEIVER SCREW  
278-RECEIVER WASHER  
280-SEAR PIN  
282-HAMMER AXIS  
283-FRONT SIGHT LOCK SCREW  
284-BARREL EXTENSION PIN  
285-FRONT SIGHT LOCK NUT  
286-FOREND PIN  
288-F.E. LOCK RETAINING RING  
290-MAG SNAP E-RING  
294-O'RING  
296-PISTON PIN  
298-TRIGGER AXIS  
299-GAS BLOCK PIN  
310-MAGAZINE ASSEMBLY

## SU-16B RIFLE PARTS LIST

Part # 202 Exchange Only

102-BARREL NUT  
104-BARREL EXTENSION  
106-FRAME BUSHING  
108-BARREL RETAINER  
110-BOLT  
112-EXTRACTOR  
114-EXTRACTOR AXIS  
116-EJECTOR  
118-FIRING PIN  
120-BOLT CARRIER  
122-OPERATING HANDLE  
124-PISTON ROD  
126-CAM PIN  
128-RECOIL SPRING CATCH  
130-PISTON HEAD  
132-RECOIL SPRING TUBE  
134-FIRING PIN PIN  
136-GAS BLOCK  
138-GAS HEAD  
140-TRIGGER BLOCK  
142-HAMMER  
144-SEAR  
145-SEAR SPRING PIN  
146-SAFETY  
148-FOREND AXIS  
150-STOCK SPACER-16  
152-MAG SNAP PIN-SHORT  
154-SPACER-29  
158-ASSEMBLY PIN  
159-MAG SNAP PIN-LONG  
172-FOREND LOCK SPRING  
174-RECOIL SPRING  
176-MAGAZINE CATCH SPRING  
178-HAMMER SPRING  
180-SEAR SPRING  
182-TRIGGER SPRING  
186-STOCK PIN SPRING  
188-MAGAZINE SNAP SPRING  
190-BOLT STOP SPRING  
192-FOREND SPREADER SPRING  
194-EXTRACTOR SPRING  
196-EJECTOR SPRING  
198-MAGAZINE SPRING  
202-RECEIVER  
203-DRIVER HOUSING  
204-MAG WELL  
205-PHILLIPS DRIVER  
207-RED O'RING  
208-TRIGGER  
210-EXTRACTOR SPRING BUFFER  
212-STOCK-RIGHT  
214-STOCK-LEFT  
216-RECEIVER SPREADER  
218-FOREND-RIGHT  
220-FOREND-LEFT  
226-FOREND LOCK  
228-BOLT STOP  
234-MAG CATCH  
244-RECOIL PAD  
252-MAGAZINE HOUSING  
254-MAGAZINE FOLLOWER  
256-MAGAZINE PLATE  
258-MAGAZINE BOTTOM  
268-SAFETY/OPERATION MANUAL  
274-EJECTOR PIN  
276-RECEIVER SCREW  
278-RECEIVER WASHER  
280-SEAR PIN  
282-HAMMER AXIS  
284-BARREL EXTENSION PIN  
286-FOREND PIN  
288-F.E. LOCK RETAINING RING  
290-MAG SNAP E-RING  
294-O'RING  
296-PISTON PIN  
298-TRIGGER AXIS  
299-GAS BLOCK PIN  
300-AIR WEIGHT BARREL  
310-MAGAZINE ASSEMBLY  
321-ALUMINUM FRONT SIGHT  
322-ALUMINUM FRONT SIGHT SET SCREW  
355-FRONT SIGHT POST  
357-FRONT SIGHT DETENT PIN

## SU-16C RIFLE PARTS LIST

Part # 202 Exchange Only

102-BARREL NUT  
103-BARREL CARBINE  
104-BARREL EXTENSION  
108-BARREL RETAINER  
110-BOLT  
112-EXTRACTOR  
114-EXTRACTOR AXIS  
116-EJECTOR  
118-FIRING PIN  
124-PISTON ROD  
126-CAM PIN  
128-RECOIL SPRING CATCH  
130-PISTON HEAD  
132-RECOIL SPRING TUBE  
137-GAS BLOCK FRONT SIGHT  
140-TRIGGER BLOCK  
142-HAMMER  
144-SEAR  
145-SEAR SPRING PIN  
146-SAFETY  
148-FOREND AXIS  
150-STOCK SPACER-16  
154-SPACER-29  
158-ASSEMBLY PIN  
172-FOREND LOCK SPRING  
174-RECOIL SPRING  
176-MAGAZINE CATCH SPRING  
178-HAMMER SPRING  
180-SEAR SPRING  
182-TRIGGER SPRING  
186-STOCK PIN SPRING  
190-BOLT STOP SPRING  
192-FOREND SPREADER SPRING  
194-EXTRACTOR SPRING  
196-EJECTOR SPRING  
198-MAGAZINE SPRING  
202-RECEIVER  
203-DRIVER HOUSING  
204-MAG WELL  
205-PHILLIPS DRIVER  
207-RED O'RING  
208-TRIGGER  
210-EXTRACTOR SPRING BUFFER  
216-RECEIVER SPREADER  
218-FOREND-RIGHT  
220-FOREND-LEFT  
226-FOREND LOCK  
228-BOLT STOP  
234-MAG CATCH  
252-MAGAZINE HOUSING  
254-MAGAZINE FOLLOWER  
256-MAGAZINE PLATE  
258-MAGAZINE BOTTOM  
268-SAFETY/OPERATION MANUAL  
274-EJECTOR PIN  
276-RECEIVER SCREW  
278-RECEIVER WASHER  
280-SEAR PIN  
282-HAMMER AXIS  
284-BARREL EXTENSION PIN  
286-FOREND PIN  
288-F.E. LOCK RETAINING RING  
294-O'RING  
296-PISTON PIN  
298-TRIGGER AXIS  
299-GAS BLOCK PIN  
310-MAGAZINE ASSEMBLY  
355-FRONT SIGHT POST  
357-FRONT SIGHT DETENT PIN  
365-REAR PEEP SIGHT  
367-REAR SIGHT ADJUSTER  
384-FRONT SIGHT DETENT PIN SPRING  
402-BARREL THREAD PROTECTOR  
412-FOLDING GRIP RIGHT  
413-STOCK LOCK  
414-FOLDING GRIP LEFT  
420-C-BOLT CARRIER  
422-DYNAMIC DEFLECTOR  
434-C-FIRING PIN PIN  
438-C-GAS HEAD  
444-FOLDING STOCK  
454-SPACER-21  
472-FOLDING STOCK SNAP LEFT  
475-FOLDING STOCK SNAP RIGHT  
476-FOLDING STOCK SNAP PIN  
478-FOLDING STOCK SNAP SPRING  
480-DUST COVER  
481-DUST COVER SCREW  
490-STOCK CAP

## SU-16CA RIFLE PARTS LIST

Part # 202 Exchange Only

102-BARREL NUT  
103-BARREL CARBINE  
104-BARREL EXTENSION  
108-BARREL RETAINER  
110-BOLT  
112-EXTRACTOR  
114-EXTRACTOR AXIS  
116-EJECTOR  
118-FIRING PIN  
124-PISTON ROD  
126-CAM PIN  
128-RECOIL SPRING CATCH  
130-PISTON HEAD  
132-RECOIL SPRING TUBE  
137-GAS BLOCK FRONT SIGHT  
140-TRIGGER BLOCK  
142-HAMMER  
144-SEAR  
145-SEAR SPRING PIN  
146-SAFETY  
148-FOREND AXIS  
150-STOCK SPACER-16  
152-MAG SNAP PIN-SHORT  
154-SPACER-29  
158-ASSEMBLY PIN  
159-MAG SNAP PIN-LONG  
172-FOREND LOCK SPRING  
174-RECOIL SPRING  
176-MAGAZINE CATCH SPRING  
178-HAMMER SPRING  
180-SEAR SPRING  
182-TRIGGER SPRING  
186-STOCK PIN SPRING  
188-MAGAZINE SNAP SPRING  
190-BOLT STOP SPRING  
192-FOREND SPREADER SPRING  
194-EXTRACTOR SPRING  
196-EJECTOR SPRING  
198-MAGAZINE SPRING  
202-RECEIVER  
203-DRIVER HOUSING  
204-MAG WELL  
205-PHILLIPS DRIVER  
207-RED O'RING  
208-TRIGGER  
210-EXTRACTOR SPRING BUFFER  
212-STOCK-RIGHT  
214-STOCK-LEFT  
216-RECEIVER SPREADER  
218-FOREND-RIGHT  
220-FOREND-LEFT  
226-FOREND LOCK  
228-BOLT STOP  
234-MAG CATCH  
244-RECOIL PAD  
252-MAGAZINE HOUSING  
254-MAGAZINE FOLLOWER  
256-MAGAZINE PLATE  
258-MAGAZINE BOTTOM  
268-SAFETY/OPERATION MANUAL  
274-EJECTOR PIN  
276-RECEIVER SCREW  
278-RECEIVER WASHER  
280-SEAR PIN  
282-HAMMER AXIS  
284-BARREL EXTENSION PIN  
286-FOREND PIN  
288-F.E. LOCK RETAINING RING  
290-MAG SNAP E-RING  
294-O'RING  
296-PISTON PIN  
298-TRIGGER AXIS  
299-GAS BLOCK PIN  
310-MAGAZINE ASSEMBLY  
355-FRONT SIGHT POST  
357-FRONT SIGHT DETENT PIN  
365-REAR PEEP SIGHT  
367-REAR SIGHT ADJUSTER  
384-FRONT SIGHT DETENT PIN SPRING  
402-BARREL THREAD PROTECTOR  
420-C-BOLT CARRIER  
422-DYNAMIC DEFLECTOR  
434-C-FIRING PIN PIN  
438-C-GAS HEAD  
480-DUST COVER  
481-DUST COVER SCREW