




KEL TEC

SU-16B Exclusive Parts

Part# 202 Exchange Only



- 202 RECEIVER
- 276 RECEIVER SCREW
- 300 AIR WEIGHT BARREL
- 321 ALUMINUM FRONT SIGHT
- 322 ALUMINUM FRONT SIGHT SET SCREW
- 355 FRONT SIGHT POST
- 357 FRONT SIGHT DETENT PIN
- 365 REAR PEEP SIGHT
- 367 REAR SIGHT ADJUSTER
- 384 FRONT SIGHT DETENT PIN SPRING



K&E SU-16 RIFLE

Part# 202 Exchange Only

310-MAGAZINE ASSEMBLY

SU-16A RIFLE PARTS LIST

Part # 202 Exchange Only

100-BARREL
102-BARREL NUT
104-BARREL EXTENSION
108-BARREL RETAINER
110-BOLT
112-EXTRACTOR
114-EXTRACTOR AXIS
116-EJECTOR
118-FIRING PIN
120-BOLT CARRIER
122-OPERATING HANDLE
124-PISTON ROD
126-CAM PIN
128-RECOIL SPRING CATCH
130-PISTON HEAD
132-RECOIL SPRING TUBE
134-FIRING PIN PIN
136-GAS BLOCK
138-GAS HEAD
140-TRIGGER BLOCK
142-HAMMER
144-SEAR
145-SEAR SPRING PIN
146-SAFETY
148-FOREND AXIS
150-STOCK SPACER-16
152-MAG SNAP PIN-SHORT
154-SPACER-29
158-ASSEMBLY PIN
159-MAG SNAP PIN-LONG
172-FOREND LOCK SPRING
174-RECOIL SPRING
176-MAGAZINE CATCH SPRING
178-HAMMER SPRING
180-SEAR SPRING
182-TRIGGER SPRING
186-STOCK PIN SPRING
188-MAGAZINE SNAP SPRING
190-BOLT STOP SPRING
192-FOREND SPREADER SPRING
194-EXTRACTOR SPRING
196-EJECTOR SPRING
198-MAGAZINE SPRING
202-RECEIVER
203-DRIVER HOUSING
204-MAG WELL
205-PHILLIPS DRIVER
206-FRONT SIGHT
207-RED O'RING
208-TRIGGER
210-EXTRACTOR SPRING BUFFER
212-STOCK-RIGHT
214-STOCK-LEFT
216-RECEIVER SPREADER
218-FOREND-RIGHT
220-FOREND-LEFT
226-FOREND LOCK
228-BOLT STOP
230-REAR SIGHT-PEEP
232-REAR SIGHT LOCK
234-MAG CATCH
236-FRONT SIGHT SCREW
240-FRONT SIGHT POST
244-RECOIL PAD
252-MAGAZINE HOUSING
254-MAGAZINE FOLLOWER
256-MAGAZINE PLATE
258-MAGAZINE BOTTOM
268-SAFETY/OPERATION MANUAL
274-EJECTOR PIN
276-RECEIVER SCREW
278-RECEIVER WASHER
280-SEAR PIN
282-HAMMER AXIS
283-FRONT SIGHT LOCK SCREW
284-BARREL EXTENSION PIN
285-FRONT SIGHT LOCK NUT
286-FOREND PIN
288-F.E. LOCK RETAINING RING
290-MAG SNAP E-RING
294-O'RING
296-PISTON PIN
298-TRIGGER AXIS
299-GAS BLOCK PIN
310-MAGAZINE ASSEMBLY

SU-16B RIFLE PARTS LIST

Part # 202 Exchange Only

102-BARREL NUT
104-BARREL EXTENSION
106-FRAME BUSHING
108-BARREL RETAINER
110-BOLT
112-EXTRACTOR
114-EXTRACTOR AXIS
116-EJECTOR
118-FIRING PIN
120-BOLT CARRIER
122-OPERATING HANDLE
124-PISTON ROD
126-CAM PIN
128-RECOIL SPRING CATCH
130-PISTON HEAD
132-RECOIL SPRING TUBE
134-FIRING PIN PIN
136-GAS BLOCK
138-GAS HEAD
140-TRIGGER BLOCK
142-HAMMER
144-SEAR
145-SEAR SPRING PIN
146-SAFETY
148-FOREND AXIS
150-STOCK SPACER-16
152-MAG SNAP PIN-SHORT
154-SPACER-29
158-ASSEMBLY PIN
159-MAG SNAP PIN-LONG
172-FOREND LOCK SPRING
174-RECOIL SPRING
176-MAGAZINE CATCH SPRING
178-HAMMER SPRING
180-SEAR SPRING
182-TRIGGER SPRING
186-STOCK PIN SPRING
188-MAGAZINE SNAP SPRING
190-BOLT STOP SPRING
192-FOREND SPREADER SPRING
194-EXTRACTOR SPRING
196-EJECTOR SPRING
198-MAGAZINE SPRING
202-RECEIVER
203-DRIVER HOUSING
204-MAG WELL
205-PHILLIPS DRIVER
207-RED O'RING
208-TRIGGER
210-EXTRACTOR SPRING BUFFER
212-STOCK-RIGHT
214-STOCK-LEFT
216-RECEIVER SPREADER
218-FOREND-RIGHT
220-FOREND-LEFT
226-FOREND LOCK
228-BOLT STOP
234-MAG CATCH
244-RECOIL PAD
252-MAGAZINE HOUSING
254-MAGAZINE FOLLOWER
256-MAGAZINE PLATE
258-MAGAZINE BOTTOM
268-SAFETY/OPERATION MANUAL
274-EJECTOR PIN
276-RECEIVER SCREW
278-RECEIVER WASHER
280-SEAR PIN
282-HAMMER AXIS
284-BARREL EXTENSION PIN
286-FOREND PIN
288-F.E. LOCK RETAINING RING
290-MAG SNAP E-RING
294-O'RING
296-PISTON PIN
298-TRIGGER AXIS
299-GAS BLOCK PIN
300-AIR WEIGHT BARREL
310-MAGAZINE ASSEMBLY
321-ALUMINUM FRONT SIGHT
322-ALUMINUM FRONT SIGHT SET SCREW
355-FRONT SIGHT POST
357-FRONT SIGHT DETENT PIN

SU-16C RIFLE PARTS LIST

Part # 202 Exchange Only

102-BARREL NUT
103-BARREL CARBINE
104-BARREL EXTENSION
108-BARREL RETAINER
110-BOLT
112-EXTRACTOR
114-EXTRACTOR AXIS
116-EJECTOR
118-FIRING PIN
124-PISTON ROD
126-CAM PIN
128-RECOIL SPRING CATCH
130-PISTON HEAD
132-RECOIL SPRING TUBE
137-GAS BLOCK FRONT SIGHT
140-TRIGGER BLOCK
142-HAMMER
144-SEAR
145-SEAR SPRING PIN
146-SAFETY
148-FOREND AXIS
150-STOCK SPACER-16
154-SPACER-29
158-ASSEMBLY PIN
172-FOREND LOCK SPRING
174-RECOIL SPRING
176-MAGAZINE CATCH SPRING
178-HAMMER SPRING
180-SEAR SPRING
182-TRIGGER SPRING
186-STOCK PIN SPRING
190-BOLT STOP SPRING
192-FOREND SPREADER SPRING
194-EXTRACTOR SPRING
196-EJECTOR SPRING
198-MAGAZINE SPRING
202-RECEIVER
203-DRIVER HOUSING
204-MAG WELL
205-PHILLIPS DRIVER
207-RED O'RING
208-TRIGGER
210-EXTRACTOR SPRING BUFFER
216-RECEIVER SPREADER
218-FOREND-RIGHT
220-FOREND-LEFT
226-FOREND LOCK
228-BOLT STOP
234-MAG CATCH
252-MAGAZINE HOUSING
254-MAGAZINE FOLLOWER
256-MAGAZINE PLATE
258-MAGAZINE BOTTOM
268-SAFETY/OPERATION MANUAL
274-EJECTOR PIN
276-RECEIVER SCREW
278-RECEIVER WASHER
280-SEAR PIN
282-HAMMER AXIS
284-BARREL EXTENSION PIN
286-FOREND PIN
288-F.E. LOCK RETAINING RING
294-O'RING
296-PISTON PIN
298-TRIGGER AXIS
299-GAS BLOCK PIN
310-MAGAZINE ASSEMBLY
355-FRONT SIGHT POST
357-FRONT SIGHT DETENT PIN
365-REAR PEEP SIGHT
367-REAR SIGHT ADJUSTER
384-FRONT SIGHT DETENT PIN SPRING
402-BARREL THREAD PROTECTOR
412-FOLDING GRIP RIGHT
413-STOCK LOCK
414-FOLDING GRIP LEFT
420-C-BOLT CARRIER
422-DYNAMIC DEFLECTOR
434-C-FIRING PIN PIN
438-C-GAS HEAD
444-FOLDING STOCK
454-SPACER-21
472-FOLDING STOCK SNAP LEFT
475-FOLDING STOCK SNAP RIGHT
476-FOLDING STOCK SNAP PIN
478-FOLDING STOCK SNAP SPRING
480-DUST COVER
481-DUST COVER SCREW
490-STOCK CAP

SU-16CA RIFLE PARTS LIST

Part # 202 Exchange Only

102-BARREL NUT
103-BARREL CARBINE
104-BARREL EXTENSION
108-BARREL RETAINER
110-BOLT
112-EXTRACTOR
114-EXTRACTOR AXIS
116-EJECTOR
118-FIRING PIN
124-PISTON ROD
126-CAM PIN
128-RECOIL SPRING CATCH
130-PISTON HEAD
132-RECOIL SPRING TUBE
137-GAS BLOCK FRONT SIGHT
140-TRIGGER BLOCK
142-HAMMER
144-SEAR
145-SEAR SPRING PIN
146-SAFETY
148-FOREND AXIS
150-STOCK SPACER-16
152-MAG SNAP PIN-SHORT
154-SPACER-29
158-ASSEMBLY PIN
159-MAG SNAP PIN-LONG
172-FOREND LOCK SPRING
174-RECOIL SPRING
176-MAGAZINE CATCH SPRING
178-HAMMER SPRING
180-SEAR SPRING
182-TRIGGER SPRING
186-STOCK PIN SPRING
188-MAGAZINE SNAP SPRING
190-BOLT STOP SPRING
192-FOREND SPREADER SPRING
194-EXTRACTOR SPRING
196-EJECTOR SPRING
198-MAGAZINE SPRING
202-RECEIVER
203-DRIVER HOUSING
204-MAG WELL
205-PHILLIPS DRIVER
207-RED O'RING
208-TRIGGER
210-EXTRACTOR SPRING BUFFER
212-STOCK-RIGHT
214-STOCK-LEFT
216-RECEIVER SPREADER
218-FOREND-RIGHT
220-FOREND-LEFT
226-FOREND LOCK
228-BOLT STOP
234-MAG CATCH
244-RECOIL PAD
252-MAGAZINE HOUSING
254-MAGAZINE FOLLOWER
256-MAGAZINE PLATE
258-MAGAZINE BOTTOM
268-SAFETY/OPERATION MANUAL
274-EJECTOR PIN
276-RECEIVER SCREW
278-RECEIVER WASHER
280-SEAR PIN
282-HAMMER AXIS
284-BARREL EXTENSION PIN
286-FOREND PIN
288-F.E. LOCK RETAINING RING
290-MAG SNAP E-RING
294-O'RING
296-PISTON PIN
298-TRIGGER AXIS
299-GAS BLOCK PIN
310-MAGAZINE ASSEMBLY
355-FRONT SIGHT POST
357-FRONT SIGHT DETENT PIN
365-REAR PEEP SIGHT
367-REAR SIGHT ADJUSTER
384-FRONT SIGHT DETENT PIN SPRING
402-BARREL THREAD PROTECTOR
420-C-BOLT CARRIER
422-DYNAMIC DEFLECTOR
434-C-FIRING PIN PIN
438-C-GAS HEAD
480-DUST COVER
481-DUST COVER SCREW